TECHNICAL SPECIFICATIONS	
LASER SOURCE AND WAVELENGTH	ND: YAG 1064 nm
IMPULSE TIME	0,1 ÷ 6 ms
SPOT DIAMETER	0,2 ÷ 1,5 mm
EXTERNAL CONTROL	APP ON MOBILE
INPUT POWER	110/230 V AC, 50/60 Hz
MAX POWER	1,8 kW
AVERAGE POWER	150 W
AMPERE	T16A
DIMENSION	340X340X340 cm
WEIGHT	15 kg
COOLING	LIQUID
WORKING ENVIROMENT	17-35°C UR 65% NON-CONDENSING

OMEC s.n.c.
Via dell' Artigianato, 3/5/7
20835 Muggiò (MB) - Italy
Tel. +39 039.79.37.40 r.a.
Fax +39 039.27.80.689
E-mail: export@omec-snc.com

E-mail: export@omec-snc.com
Web site: www.omecitalia.com
Skype: omecsnc



DADO is also

and price.

a LASER READY TO GO,

the best in terms of

technological quality

The huge investment

and industrialization

of this product has

customer a welder

led us to give the final

at an incredible price!

APPLICATION PROPRIETOR



DADO is supplied with an App, which univocally links to the serial of the product. This App allows full control of the laser and all its parameters.



SIZE

DADO is small, light, can be easily placed anywhere: from the small workshop directly on the workbench or dental technician laboratory.

LABORATORY DENTAL

FOR

DENTAL Fixation of parts of orthodontic appliances. Porosity fixing after casting. Fixing attachments, joints, brackets and anchors. Dentures adjusting, bridges, caps and implants.

ELDING

≥

SISTANT CAL 0



DADO can be used with Thanks to the voice synthesis card, Download the APP now it provides the operator from the Google market with all the information he needs, including any error status. It works even without a smartphone.

place or from the Apple Thanks to the dedicated application, the machine will be under your

control. At the same time, the laser "speaks" and aives you the indications and the working mode states.

WApp

your smartphone.

store.



INDICATOR

ATUS

ST

LIGHTS



The variable color of the LEDs in the welding chamber is also another indicator of the laser status. The same LEDs change the color relating to the laser working status: standby, in low or high power operation mode.



CESSOR

AC

FULL

- · Power supply cable. · Foot pedal for shot..
- 1lt of Distilled and deionized water tank ready to use.
- · Support for smartphone.
- · Allen key for adjustments and fixing microscope.
- Customized little tweezers for use in the work chamber.
- · Welding cleaning brush. Alloy wire for welding.
- · Customized microfiber cloth for cleaning.



a smartphone.

It will become

HMI (Human Machine

Interface), very useful

for all those who

will use DADO.

RFACE

Ξ

Ш

0

DADO can be used Unbox, fill, plug-in with or without and start welding Take full advantage The laser does of the potential provided by the APP, installations. using the supplied Today welding support and positioning the smartphone. immediately an evolved

ELD ≥ Ω Z V Ü PLU



whatever you want. not require special is almost a child's play.